

4300 WINDFERN RD #100 HOUSTON TX 77041-8943 VOICE (713) 973-6905 FAX (713) 973-9352 web: www.twrlighting.com

IMPORTANT!!!

PLEASE TAKE THE TIME TO FILL OUT THIS FORM COMPLETELY. FILE IT IN A SAFE PLACE. IN THE EVENT YOU EXPERIENCE PROBLEMS WITH OR HAVE QUESTIONS CONCERNING YOUR CONTROLLER, THE FOLLOWING INFORMATION IS NECESSARY TO OBTAIN PROPER SERVICE AND PARTS.

MODEL #	AA2-MDF
SERIAL #	
PURCHASE DATE	
PURCHASED FROM	

TWR Lighting," Inc. WARK

Enlightened Technology®

AA2-MDF CONTROLLER

TABLE OF CONTENTS

1.0	ENERAL INFORMATION	1
2.0	NSTALLATION INSTRUCTIONS	2
	.1 Mounting the Control Cabinet	2
	.2 External Photocell Wiring	3
	.3 Power Wiring	3
	.4 Red Beacon, and Sidelight Load Balance Resistor Wiring	4
3.0	HEORY OF OPERATION	5
	.1 Power Supply	5
	.2 Sidelights	5
	.3 Beacon	5
4.0	IAINTENANCE GUIDE	6
	.1 Red Obstruction Lighting	6
	.2 L-864 Replacement	
	.3 Lamp Replacement	6
	.4 L-864 Controller	
	.5 Photocell	7
5.0	IAJOR COMPONENTS PARTS LIST	8
6.0	UGGESTED SPARE PARTS LIST	9
WARF	NTY & RETURN POLICY	

RETURN MERCHANDISE AUTHORIZATION (RMA) FORM

TWR Lighting,[®] **Inc.** WSRK Enlightened Technology[®] AA2-MDF CONTROLLER

APPENDIX

CHASSIS COMPONENT LAYOUT	214-R (REV B)
SCHEMATIC LAYOUT	214-S (REV B)
TROUBLESHOOTING FLOW CHART	214-F
PHOTOCELL HOUSING DETAIL	100239 (REV H)
TOWER LIGHTING KIT 401' TO 500'	261-33
L-810 OL-1 SINGLE OBSTRUCTION LIGHT DETAIL	279-OL (REV C)
L-810 OL-1 WIRING DETAIL	274 S (REV A)
L-864 FB 300 MM BEACON DETAIL	275-B (REV E)
L-864 FB 300 MM WIRING DETAIL	273 B
JUNCTION BOX DETAIL	100089 (REV A)
WRAPLOCK FASTENING DETAIL	



1.0 GENERAL INFORMATION

The TWR Lighting[®], Inc. (TWR[®]) Model AA2-MDF Controller is for A2 lighting of towers 351' to 700' AGL (above ground level). One (1) beacon should be placed at the top of the structure; the second beacon should be placed at the mid-point with respect to the overall tower height. One (1) set of three (3) obstruction lights should be placed between the top and lower beacon. Another set of three (3) obstruction lights should be placed between the lower beacon and the ground level.

The flash rate of the beacons is 30 per minute. The sidelights burn steady.

A by-pass switch (SW1) allows the controller to be turned on during daylight hours without covering the photocell. This is particularly helpful since the controller can be mounted indoors while the photocell is outdoors. SW1 can be operated by turning "on" the toggle switch mounted on the panel of the controller.

Each beacon requires two (2) 620 watt or two (2) 700 watt, 120V bulbs. The use of any other bulb may give a false beacon lamp burnout alarm. TWR[®] recommends that you use only these bulbs. Do not try to use 130V bulbs. Each sidelight requires one (1) 116 watt, 120V bulb (620PS40P, 700PS40P, and 116A21TS).

The photocell is the three (3) blade, twist to lock, type.

Power supplied to the controller shall be 120V AC, 50/60 Hz.

The controller housing is rated at NEMA 4X. It is suitable for indoor or outdoor mounting.



2.0 INSTALLATION INSTRUCTIONS

2.1 MOUNTING THE CONTROL CABINET

(Refer to Drawing 214-R)

The power supply control cabinet can be located at the base of the structure or in an equipment building. Mounting footprints are shown on Drawing 214-R. Power wiring to the control cabinet should be in accordance with local methods and the National Electric Codes (NEC).

- 2.1.1 If the control cabinet is mounted inside an equipment building, the photocell should be mounted vertically on ½" conduit outside the building above the eaves facing north. Wiring from the photocell socket to the control cabinet should consist of one (1) each, red, black, and white wires. The white wire is connected to the socket terminal marked "N," the black wire is connected to the socket terminal marked "Li," and the red wire is connected to the socket terminal marked "Lo." As above, the photocell should be positioned so that it does not "see" ambient light, which would prevent it from switching to the nightmode.
- 2.1.2 If the control cabinet is mounted outside an equipment building, the photocell should be mounted vertically on ½" conduit so the photocell is above the control cabinet. Care must be taken to assure that the photocell does not "see" any ambient light that would prevent it from switching into the nightmode. The photocell wiring is the same as in 2.1.1.
- 2.1.3 The wiring from the photocell, the service breaker, the red incandescent beacons, and the sidelights should enter the control cabinet through the watertight connectors in the bottom of the cabinet. Inside the cabinet, the connections will be made on the terminal strips and circuit breakers located at the bottom of the chassis. These connections are made as follows:



AA2-MDF CONTROLLER

- 2.2 <u>EXTERNAL PHOTOCELL WIRING</u> (Refer to Drawing 214-R)
 - 2.2.1 Connect the **BLACK** wire from the photocell to terminal block TB2 marked "L."
 - 2.2.2 Connect the **<u>RED</u>** wire from the photocell to terminal block TB2 marked "SSR."
 - 2.2.3 Connect the <u>WHITE</u> wire from the photocell to terminal block TB2 marked "N."

2.3 POWER WIRING

(Refer to Drawing 214-R)

- 2.3.1 Power wiring to the control cabinet should be in accordance with local methods and the National Electric Code (NEC).
- 2.3.2 Circuit breaker needs to be rated at 35 amps.
- 2.3.3 Connect incoming 120V AC line to terminal block TB1 marked "L."
- 2.3.4 Connect the neutral wire(s) to one (1) of the terminal blocks on TB1 marked "N."
- 2.3.5 Connect the AC ground to the aluminum mounting plate.



2.4 <u>RED BEACON, and SIDELIGHT LOAD BALANCE RESISTOR WIRING</u> (Refer to Drawings 214-R, 261-2B, 361-11, and 361-12)

Install wiring between the controller and the beacon utilizing either strobe cable or conduit method. Refer to Drawings 214-R, 361-11, and 361-12, for installation of light kits. Following these requirements, installing light kits will require lifting of the cable by the supplied cable grip or conduit to affix to the tower. Always work safely and adhere to all OSHA Safety Guidelines when lifting wiring or working on the structure or tower itself. It is the installer's responsibility to install the lighting kit in a safe manner. Installers can request from OSHA their requirements 29CFT 1926.21, and 29CFR 1926.105 to ensure compliance to regulations.

- <u>NOTE</u>: On occasion, a set of custom lighting kit drawings may be specifically requested by a customer and installed in this manual. In cases such as this, the drawings will precede the manual if a conflict occurs.
- 2.4.1 Connect the **BLACK** wire from the top beacon to the circuit breaker marked "B1."
- 2.4.2 Connect the **BLACK** wire from the middle beacon to the circuit breaker marked "B2."
- 2.4.3 Connect the <u>**RED**</u> wires from both sidelight groups to the circuit breaker marked "S."
- 2.4.4 Connect the **NEUTRAL** wire(s) to one of the terminal blocks on TB1 marked "N."



3.0 THEORY OF OPERATION

3.1 **POWER SUPPLY**

120V AC enters the controller from the circuit breaker panel. Line sits at the PRD, waiting to be switched. When the 6390-FAA photocell is activated, line energizes the coil of the PRD. This also can be accomplished by using the photocell by-pass switch (SW1).

3.2. SIDELIGHTS

Line LD is sent directly to the circuit breaker marked "S."

3.3 BEACON

Line LDB is sent to the Motor Driven Flasher, which is the primary flasher for the beacons that provides control voltage. The outputs of the Motor Driven Flasher are sent to the circuit breakers marked "B1" and "B2."



4.0 MAINTENANCE

4.1 RED OBSTRUCTION LIGHTING

The only required maintenance needed to be performed is replacement of the lamps in the L-864 and L-810 fixtures. Lamps should be replaced after being operated for not more than 75% of the rated life or immediately upon failure as per Federal Advisory Circular 70/7460-1K. By following these instructions, maximum safety and performance can be achieved.

TOOLS REQUIRED: NONE

4.2 L-864 LAMP REPLACEMENT

- 4.2.1 Loosen the one (1) wing nut on the latch pin so that it can recline.
- 4.2.2 Open the lens and tilt it back.
- 4.2.3 To remove each lamp, depress down while rotating the lamp counter-clockwise 90°.
- 4.2.4 Install the new lamps by depressing down while rotating the lamp clockwise 90°.
- 4.2.5 Close the lens and let the latch pin drop in the recessed slot.
- 4.2.6 Tighten the wing nut snug, then 1/4 turn more.

4.3 LAMP REPLACEMENT

- 4.3.1 Unclasp the two (2) latches and let the bail recline back.
- 4.3.2 Lift the lens up and over the lamp, letting the lens hang from the safety cable.
- 4.3.3 Unscrew the lamp counter-clockwise and remove.
- 4.3.4 Install the new lamp by screwing the lamp clockwise.



- 4.3.5 Reinstall the lens, making sure it is seated properly on the base.
- 4.3.6 Reclasp the two (2) latches.

4.4 <u>L-864 CONTROLLER</u>

No scheduled maintenance is required. Perform on an "as needed" basis only.

4.5 PHOTOCELL

The photocell is a sealed unit. No maintenance is needed or required other than replacement as necessary.

TWR Lighting,[®] Inc. WARK Enlightened Technology[®]

AA2-MDF CONTROLLER

5.0 MAJOR COMPONENTS PARTS LIST

QTY	PART NUMBER	DESCRIPTION
1	6390-FAA (This replaces the 102FAA Photocell)	120 – 240V Photocell
1	22-02	Motor Driven Flasher
1	PRD7AGO	Mechanical Load Contactor (PRD)
1	VJ1008HWPL1X004	Enclosure
1	STJ01002	15 amp SPDT Switch (SW1)
1	MOV524V15	Metal Oxide Varistor (MOV)
3	S261D20	20 amp Circuit Breaker (B1, B2, and S)
2	8WA1808	End Stop
6	8WA1204	Terminal Blocks (TB1, TB2)
1	SSPIGTAIL	20' Pigtail



AA2-MDF CONTROLLER

6.0 SUGGESTED SPARE PARTS LIST

QTY	PART NUMBER	DESCRIPTION
1	6390-FAA (This replaces the 102FAA Photocell)	120 – 240V Photocell
1	22-02	Motor Driven Flasher
1	PRD7AGO	Load Contactor (PRD)



Warranty & Return Policy

TWR Lighting[®], **Inc. ("TWR[®]") warrants its products (other than "LED Product")** against defects in design, material (excluding incandescent bulbs) and workmanship for a period ending on the earlier of two (2) years from the date of shipment or one (1) year from the date of installation.

TWR Lighting®, **Inc.** ("**TWR®**") **warrants its "LED Product**" against defects in design, material and workmanship for a period of five (5) years from the date of shipment. TWR®, at its sole option, will, itself, or through others, repair, replace or refund the purchase price paid for "LED Product" that TWR® verifies as being inoperable due to original design, material, or workmanship. All warranty replacement "LED Product" is warranted only for the remainder of the original warranty of the "LED Product" replaced. Replacement "LED Product" will be equivalent in function, but not necessarily identical, to the replaced "LED Product."

TWR Lighting[®], **Inc.** ("**TWR**[®]") **warrants its "LED Product"** against light degradation for a period of five (5) years from the date of installation. TWR[®], at its sole option, will, itself, or through others, repair, replace, or refund the purchase price paid for "LED Product" that TWR[®] verifies as failing to meet 75% of the minimum intensity requirements as defined in the FAA Advisory Circular 150/5345-43G dated 09/26/12. All warranty replacement "LED Product" is warranted only for the remainder of the original warranty of the "LED Product" replaced. Replacement "LED Product" will be equivalent in function, but not necessarily identical, to the replaced "LED Product."

Replacement parts (other than "LED Product") are warranted for 90 days from the date of shipment.

Conditions not covered by this Warranty, or which might **void** this Warranty are as follows:

- x Improper Installation or Operation
- x Misuse
- x Abuse
- x Unauthorized or Improper Repair or Alteration
- x Accident or Negligence in Use, Storage, Transportation, or Handling
- x Any Acts of God or Nature
- x Non-OEM Parts

The use of Non-OEM parts or modifications to original equipment design will void the manufacturer warranty and could invalidate the assurance of complying with FAA requirements as published in Advisory Circular 150/5345-43.



Warranty & Return Policy (continued)

Field Service – Labor, Travel, and Tower Climb are not covered under warranty. Customer shall be obligated to pay for all incurred charges. An extensive network of certified and insured Service Representatives is available if requested.

Return Terms – You must first contact our Customer Service Department at **713-973-6905** to acquire a Return Merchandise Authorization (RMA) number in order to return the product(s). Please have the following information available when requesting an RMA number:

- x The contact name and phone number of the tower owner
- x The contact name and phone number of the contractor
- x The site name and number
- x The part number(s)
- x The serial number(s) (if any)
- x A description of the problem
- x The billing information
- x The Ship To address

This RMA number must be clearly visible on the outside of the box. If the RMA number is not clearly labeled on the outside of the box, your shipment will be refused. Please ensure the material you are returning is packaged carefully. The warranty is null and void if the product(s) are damaged in the return shipment.

All RMAs must be received by TWR LIGHTING[®], INC., 4300 WINDFERN RD #100, HOUSTON TX 77041-8943, within 30 days of issuance.

Upon full compliance with the Return Terms, TWR[®] will replace, repair and return, or credit product(s) returned by the customer. It is TWR[®]'s sole discretion to determine the disposition of the returned item(s).



Warranty & Return Policy (continued)

<u>Replacements</u> – Replacement part(s) will be shipped and billed to the customer for product(s) considered as Warranty, pending return of defective product(s). When available, a certified reconditioned part is shipped as warranty replacement with a Return Merchandise Authorization (RMA) number attached. Upon receipt of returned product(s), inspection, testing, and evaluation will be performed to determine the cause of defect. The customer is then notified of the determination of the testing.

- x Product(s) that is deemed defective and/or unrepairable and covered under warranty a credit will be issued to the customer's account.
- x Product(s) found to have no defect will be subject to a **\$75.00 per hour testing charge (1 hour minimum), which will be invoiced to the customer.** At this time the customer may decide to have the tested part(s) returned and is responsible for the return charges.
- x Product(s) under warranty, which the customer does not wish returned, the customer will be issued a credit against the replacement invoice.

<u>Repair & Return</u> – A Return Merchandise Authorization (RMA) will be issued for all part(s) returned to TWR[®] for repair. Upon receipt of returned product(s), inspection, testing, and evaluation will be performed to determine the cause of defect. The customer is then notified of the determination of the testing. If the returned part(s) is deemed unrepairable, or the returned part(s) is found to have no defect, the customer will be subject to a **\$75.00 per hour testing charge (1 hour minimum), which will be invoiced to the customer.** Should the returned parts be determined to be repairable, a written estimated cost of repair will be sent to the customer for their written approval prior to any work being performed. In order to have the tested part(s) repaired and/or returned, the customer must issue a purchase order and is responsible for the return shipping charges.

<u>**Return to Stock**</u> – Any order that is returned to TWR^{\circledast} for part(s) ordered incorrectly by the customer, or unneeded upon receipt, the customer is required to pay a **20% restocking fee**. A credit will be issued once it is determined that the Return Terms are met.

<u>Credits</u> – Credits are issued once it is determined that all of the Warranty and Return Terms are met. All credits are processed on Fridays. In the event a Friday falls on a Holiday, the credit will be issued on the following Friday.

Freight – All warranty replacement part(s) will be shipped via ground delivery and paid for by TWR[®]. Delivery other than ground is the responsibility of the customer.



Warranty & Return Policy (continued)

REMEDIES UNDER THIS WARRANTY ARE LIMITED TO PROVISIONS OF REPLACEMENT PARTS AND REPAIRS AS SPECIFICALLY PROVIDED. IN NO EVENT SHALL TWR® BE LIABLE FOR ANY OTHER LOSSES, DAMAGES, COSTS, OR EXPENSES INCURRED BY THE CUSTOMER, INCLUDING, BUT NOT LIMITED TO, LOSS FROM FAILURE OF THE PRODUCT(S) TO OPERATE FOR ANY TIME, AND ALL OTHER DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, INCLUDING ALL PERSONAL INJURY OR PROPERTY DAMAGE DUE TO ALLEGED NEGLIGENCE, OR ANY OTHER LEGAL THEORY WHATSOEVER. THIS WARRANTY IS MADE BY TWR® EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, WHETHER EXPRESSED OR IMPLIED. WITHOUT LIMITING THE GENERALITY OF THE FORGOING, TWR® MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS OF THE PRODUCT(S) FOR ANY PARTICULAR PURPOSE. TWR® EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES.



RETURN MATERIAL AUTHORIZATION (RMA) FORM


RMA#:	_DATE:
CUSTOMER:	
	PHONE NO.:
ITEM DESCRIPTION (PART NO.):
	_SERIAL NO.:
ORIGINAL TWR INVOICE NO .: _	DATED:
DESCRIPTION OF PROBLEM:	
	DATE NEEDED
RETURN ADDRESS: PLEASE RETURN PRODUCT TO: 430	0 WINDFERN RD. #100 HOUSTON TX 77041-8943




RETURN MATERIAL AUTHORIZATION (RMA) FORM


RMA#:	_DATE:
CUSTOMER:	
	PHONE NO.:
	.):
	_SERIAL NO.:
ORIGINAL TWR INVOICE NO .: _	DATED:
SIGNED	DATE NEEDED
RETURN ADDRESS:	

PLEASE RETURN PRODUCT TO: 4300 WINDFERN RD. #100 HOUSTON TX 77041-8943




⊕ 	1
	2
MOUNTING DIMENSIONS (FOR CABINET)	3
G 6390-FAA PHOTOCELL INTO D9 TWIST LOCK RECEPTACLE AND T TO LOCK. ES ARE CONNECTED LETTER TO ER. (EXAMPLE) L TO L TO L	
	4
AA2-MDE (MOTOR DRIVEN FLASHER)	5
AAZ-MDF (MOTOR DRIVEN FLASHER) CHASSIS LAYOUT PROD DEPT SERV DEPT ENGINEER DRAWN BY	6
DRAWN B SHEET OTT. B 0.0 0.0 0.0 DATE 0.0 0.0 0.0 DATE 0.0 0.0 0.0 The use of non-OEM parts or modifications to original equipment design will void the manufacturer warranty and could invalidate the assurance of complying with FAA requirements as published in Advisory Circular 150/334543. 0.0 0.0 NOTICE: The use of non-OEM parts or modifications to original equipment design will void the manufacturer warranty and could invalidate the assurance of complying with FAA requirements as published in Advisory Circular 150/334543. 0.0 0.0 NOTICE: The use of non-OEM parts or modification is not generally known shall be considered confidential except to the extent the information has been previously established. The drawings and photographic images contained herein are the sole or or any other purpose without the expressed written permission of TWR Lighting, Inc. E F	







	1
	2
	3
NO	
TOWER	K/REPAIR R WIRING
	4
NO CHECK	(/REPAIR
TOWER	WIRING
	5
TROUBLES	HOOTING FLOW CHART
PROD DEPT	<u> 1DF DWG #214-R</u>
	WR Lighting, Inc.
ENGINEER	Enlightened Technology®
DRAWN BY E.A.SALAZAR	SHEET SIZE SHEET QTY. B 1 OF 1
DATE 11/06/98 SCAI	E N.T.S. DWG. NO. 214-F
complying with FAA requirements as published in Advis NOTICE: The drawings and photographic images contained he known shall be considered confidential except to the extent the	squipment design will vold the manufacturer warranty and could invalidate the assurance of sory Circular 150/3545-43. revin are the sole property of TWR Lighting, Inc. All information contained herein that is not generally information has been previously established. The drawings and photographic images contained herein ture or sole or promotion or any other purpose without the expressed written permission of TWR
Lighting, Inc.	nue or sale of promonon of any other purpose winnon the expressed winnen permission of 1 WK



A



E	F
BILL	OF MATERIALS
TWR PART NO.	DESCRIPTION
BEACON	300 MM BEACON RED
620PS40P 0L1	620 WATT 120 VOLT LAMP 1 3/4" OBSTRUCTION LIGHT
116A21TS	116 WATT 120 VOLT LAMP
CGB295SA	3/4" CORD CONNECTOR
JB5 JB0	3/4" JUNCTION BOX 3/4" STRAIN RELIEF BOX
JB8	1" JUNCTION BOX
JB8SR	1" STRAIN RELIEF BOX 3/4" UNION
UNY205 UNY305	1" UNION
T27CG	3/4" CONDULET W/COVER AND GASKET
T37CG	1" CONDULET W/COVER AND GASKET
EL3490 EL3430	3/4"90°SHORT ELBOW 3/4"30°ELBOW
EL190	1"90°ELBOW
5012902	3/4" BREATHER
SS10012 PIPDOP	WRAPLOCK 4 oz. PIPE DOPE
A314	3/4" CONDUIT LOCKNUTS
A315	1" CONDUIT LOCKNUT 1" TO 3/4" REDUCER
RE32 CPLG34	1" TO 3/4" REDUCER 3/4" GALVANIZED COUPLING
N34T3	3/4" x 3" NIPPLE
HC402	3/4" NO THREAD CONNECTOR 3
CONDUIT34	3/4" CONDUIT (FOR OL)
SLPIGTAIL25 AA2	25' SIDELIGHT PIGTAIL AA2 CONTROLLER
	RE <u>NOT</u> INCLUDED IN THE KIT BUT ARE AND REQUIRED FOR INSTALLATION.
CONDUIT34	3/4" CONDUIT (1/2 TOWER HT.)
CONDUIT1	1" CONDUIT (1/2 TOWER HT.+ 30'/9M)
4THHNWHT	#4 THHN WHT. WIRE (TOWER HT.+40'/12M) #4 THHN BLK. WIRE (TOWER HT.+40'/12M)
4THHNBLK 8THHNWHT	#4 THHN BLK. WIRE (10WER HT.+40/12M) #8 THHN WHT. WIRE (1/2 TOWER HT.+40'/12M)
8THHNBLUE	#8 THHN BLUE WIRE $(1/2 \text{ TOWER HT.}+40'/12M)$
12THHNRED	#12 THHN RED WIRE (3/4 TWR HT.+40'/12M)
12THHNYLW	#12 THHN YLW. WIRE (1/4 TWR HT.+40'/12M)
OT SHOWN	
	-
	Ę
F	
LK1A2	TOWER LIGHTING KIT W/NO BOOST
(TOW	ERS 401'/122M TO 500'/152M)
PROD DEPT	
SERV DEPT	TWP Lidblind Ing WAR
	TWR Lighting, Inc. HARK
ENGINEER	Chtightenea 5 echnologg
DRAWN BY	SHEET SIZE SHEET QTY.
DATE 06/26	
The use of non-OEM parts or mode FAA requirements as published in a	fications to original equipment design will void the manufacturer warranty and could invalidate the assurance of complying with Advisory Circular 150/5345-43.
known shall be considered confidenti	aphic images contained herein are the sole property of TWR Lighting. Inc. All information contained herein that is not generally al except to the extent the information has been previously established. The drawings and photographic images contained herein d as the hasis for manufacture or sale or promotion or any other purpose without the expressed written permission of TWR.
Lighting, Inc.	F



В


			2	1	_
			PA	RTS LIST	
	ITEM	QTY	PART NUMBER	DESCRIPTION	
	1	1	AP35222	RED SIDELIGHT GLASS	
	2	1	105C	SINGLE SIDELIGHT BODY	
	3	1	106C	LENS HOLDER RING	
	4	2	12V245	OL LENS CLIP	
	5	2	832X14PH	8-32 X 1/4" PH SS SLOT SCREW	
	6	2	HC255SS	SIDELIGHT LATCH	
	7	1	7X7SS	1/16 HOL 7X7 S.S. WIRE	
	8	2	A1A	STAKON CRIMP	
	9	1	OLG	OL GASKET	
	10	1	TWR19062	SIDELIGHT RECEPTACLE	
	11	4	18PRSS	1/8 X .40 SS POP RIVET	
	12	1	A314	3/4" CONDUIT LOCKNUT GALV.	
*	13	2	104G	WHITE TEFLON WASHER	
	14	2	832X34PH	8-32 X 3/4" S.S. RH SLOT	В
	15	1	100327	OL1 SERIAL NUMBER LABEL	
~	16	1	116A21TS	116W-120V LAMP (TYP.)	
					1


* = PART NOT SHOWN


 \sim = PART SOLD SEPARATELY

NOTE:

1. FAA APPROVED LIGHT USES THE 116A21TS LAMP. OTHER LAMPS ARE AVAILABLE TO MEET YOUR APPLICATION.








TO JUNCTION BOX

|--|


PROD DEPT SERV DEPT ENGINEER	TWR Lighting Enlightened Tech	5,° Inc. ^{3nology®}	HARK	e
drawn by G.D. SEBEK		sheet size B	SHEET QTY. 1 OF 1	
 DATE 06/08/91	I ^{scale} N.T.S.	DWG. NO.	274–S	
FAA requirements as published in Advisory Circular				
known shall be considered confidential except to the e	tained herein are the sole property of TWR Lighting, Inc. extent the information has been previously established. The manufacture or sale or promotion or any other purpose wi	drawings and photogr	aphic images contained herein	



DRAWN J.L.BUSTAMANTE CHECKED QA	11/27/07		ТИ	/ R	Ligh	n tir nlight	1g,[®] Inc. tened Technology [®]	
MFG APPROVED		TITLE			300 MN ASSEMB	/I BEA	CON	
		SIZE B			DWG NO		275-B	rev E
		SCALE					SHEET 1 OF 1	
invalidate the assurance NOTICE: The drawings and pho known shall be considered confi	of complying w otographic images con idential except to the e	ith FAA re tained herein extent the info	equirements are the sole p ormation has b	as pub roperty of ' een previo	olished in Ad TWR Lighting, I usly established.	visory C Inc. All info The drawi	manufacturer warranty and ircular 150/5345–43. ormation contained herein that is not ings and photographic images contair the expressed written permission of T	generally ed hereir
4		2			I		1	

Α

- WHITE WIRE IS NEUTRAL TO BOTH LAMPS
 BLACK WIRE IS LINE TO BOTH LAMPS.
 GREEN WIRE IS EARTH GROUND.




В

300 MM BEACON

W

G



	•			

Α		B		С	D	E
						[
3	JB-5 AND 3/4" junctic				JB-8 AND 1" JUNCTIO	
using this	JUNCTION BOX ME	THOD SPACING	IS 100 FEET	<u></u>	NOTES: 1) DRAWING ILLUS WIRE. USE THIS 2) THE NATIONAL DEOLUDES CONT	S METHOD ELECTRICA
		RES IN 1"	WIRE AREA SQ. INCHES	WEIGHT PER 100 FEET	REQUIRES CONE SUPPORTED TO CONNECTIONS. 3) SKETCH ILLUST A SINGLE CONE	RELIEVE RATES ME
5 12 THHN 10 THHN 8 THHN 6 THHN 4 THHN		26 17 9 7 4		2.50 4.10 6.70 10.30 16.20	BE GROUPED T 4) CONDUCTORS M UP MORE THAN	OGETHER. 1AY BE MI
6						

	9/29/00	A) ä	UPDATED NOTES
	DATE:	LTR.	REVISION
0		-	

